



Member State of OIML
United Kingdom of Great Britain
and Northern Ireland

OIML Certificate No R76/2006-GB1-15.06 Revision 1

OIML CERTIFICATE OF CONFORMITY

Issuing authority: National Measurement and Regulation Office

Person responsible: Paul Dixon – Director, Technical Services

Applicant: lan Fellows Ltd

3D/E Centurion Way

Crusader Park Warminster Wiltshire BA12 8BT

United Kingdom

Manufacturer: The applicant

Identification of the

certified pattern: Checkmaster and Linemaster V

This certificate attests the conformity of the above-mentioned pattern (represented by the samples identified in the associated test report) with the requirements of the following Recommendation of the International Organisation of Legal Metrology (OIML):

OIML R 76 - Edition 2006(E) for accuracy class: [III] and [IIII]

This certificate relates only to the metrological and technical characteristics of the pattern of the instrument concerned, as covered by the relevant OIML International Recommendation.

This certificate does not bestow any form of legal international approval.

Important note: Apart from the mention of the certificates reference number and the name of the OIML Member State in which the certificate was issued, partial quotation of the certificate or of the associated test report is not permitted, though they may be reproduced in full.

This revision replaces earlier versions of the certificate.

Issue Date: 22 January 2016 Reference No: TS1201/0126

Grégory Glas

Technical Manager – NMRO Technical Services



0135

The conformity was established by testing and examination described in the associated Evaluation Report P01540 which includes 14 pages.

Characteristics of the instrument:

The instrument utilises the Checkmaster digital indicating device connected to a weighing platform to form a single-interval, Class III or IIII, non-automatic weighing instrument.

The instrument is not intended to be used for direct sales to the public.

Construction:

- Stainless steel enclosure
- LCD display (Figure 2)
- Operator keypad with numerical, navigation and function keys
- Lightbar

Devices:

- Initial zero setting device on power up (≤ 20% Max)
- Semi-automatic zero setting (≤ 4% Max)
- Zero tracking (≤ 4% Max)
- Automatic zero setting (≤ 4% Max)
- Semi-automatic subtractive tare balancing (T ≤ Max)
- Preset tare
- Gross/Net indication
- Zero-indicator
- Indication of stable equilibrium
- Net indicator
- Extended indication (e/10)

Technical data:

Power supply	100-240 VAC, 50/60 Hz	
	12-24 VDC	
Maximum number of scale intervals	10,000 (Class III)	
	1,000 (Class IIII)	
Maximum Tare / Preset Tare value	- Max	
Load cell excitation voltage	5 VDC	
Minimum load cell impedance	43 Ω	
Maximum load cell impedance	1100 Ω	
Minimum input voltage per verification	0.5 μV	
scale interval		
Measuring range minimum voltage	0 mV	
Measuring range maximum voltage	20 mV	
Fraction of maximum permissible	$P_{i} = 0.5$	
error		
Operating temperature range	- 10 °C to + 40 °C	
Load cell cable (from indicator to load	30 m (6-wire configuration)	
cell junction box) - Maximum length		

Load cell:

Any compatible load cell(s) may be used providing the following conditions are met:

- There is a respective OIML Certificate of Conformity (R60) issued for the load cell.
- The certificate contains the load cell types and the necessary load cell data required for the manufacturer's declaration of compatibility of modules, and any particular installation requirements. A load cell marked NH is allowed only if humidity testing to R76 has been conducted on this load cell.
- The compatibility of the load cells and indicator is established by the manufacturer by means of the compatibility of modules calculation at the time of verification.
- The load cell transmission conforms to a standard type.

Interfaces:

- Load cell
- RS232 x 2
- PIO x 9
- Wi-Fi
- RFID

Software:

The software is held in firmware on the circuit board, and has the identification number MC8 xxx, with xxx reflecting non-legally relevant changes.

A non-editable counter, designated TAN (traceable access number), increments when legally relevant parameters are changed.

Download of software requires a command that increments the TAN counter.

The software version number and TAN counter are displayed at power-up.

Sealing measures:

Access to the load cell connection and electronics is prevented by sealing the enclosure using either a wire and seal or a tamper evident label and securing mark. The securing mark may be either:

- a mark of the manufacturer and/or manufacturer's representative, or
- an official mark of a verification officer.

The value of the TAN counter shall be written on a tamper-evident label on or near the rating plate.

Markings:

The markings shall comply with the relevant national regulations.

Authorised alternatives:

Having a Linemaster V indicator as an alternative indicator.

OIML Certificate No R76/2006-GB1-15.06 Revision 1

CERTIFICATE HISTORY

ISSUE NO.	DATE	DESCRIPTION
R76/2006-GB1-15.06	22 July 2015	Certificate first issued.
R76/2006-GB1-15.06 Revision 1	22 January 2016	RFID added to Interfaces section.
		List of markings replaced by compliance to national regulation.
		Linemaster V indicator added as an alternative.